



Raymarine®

i70

Installation Instructions

Legal notices

Trademark and patents notice

Raymarine®, **Tacktick®**, **Pathfinder®**, **Clear Pulse®**, **Truzoom®**, **SeaTalk®**, **SeaTalk HS™**, **SeaTalk NG™**, and **MicroNet™**, are registered or claimed trademarks of Raymarine UK Ltd.

FLIR®, **Fishidy®**, **Fishing Hot Spots®**, **YachtSense™**, **DockSense®**, **RangeFusion™**, **DownVision®**, **SideVision®**, **RealVision®**, **HyperVision™**, **Wi-Fish®**, **Dragonfly®**, **Element®**, **Quantum®**, **Cyclone™**, **Alpha™**, **Axiom®**, **Infrared Everywhere**, **The World's Sixth Sense** and **ClearCruise®** are registered or claimed trademarks of Teledyne FLIR LLC.

All other trademarks, trade names, or company names referenced herein are used for identification only and are the property of their respective owners.

This product is protected by patents, design patents, patents pending, or design patents pending.

Fair Use Statement

You may print no more than three copies of this manual for your own use. You may not make any further copies or distribute or use the manual in any other way including without limitation exploiting the manual commercially or giving or selling copies to third parties.

Content notice

Please ensure that you have obtained this document only from Raymarine, and that it is the **latest** available version.

There are numerous third-party Internet websites (such as www.manualslib.com) hosting Raymarine product manuals. These websites are not authorized by Raymarine to do so, and are often hosting illegitimate or older versions of Raymarine product manuals, which may contain inaccurate or misleading information.

To obtain the latest official documentation for a Raymarine product, please visit the official Raymarine website: www.docs.raymarine.com

Artificial Intelligence (AI) content notice

There are numerous third-party **Artificial Intelligence (AI)** services available to the public, which are capable of providing a summary or transcription of the information provided by official Raymarine publications or websites, either in written or audio/video formats. These services may alter, supplement, or convey the original information provided by Raymarine in inaccurate or misleading ways.

Please ensure that you have obtained this document only from Raymarine, and that it is the **latest** available version.

CONTENTS

CHAPTER 1 IMPORTANT INFORMATION	8
Safety warnings	8
Product warnings	8
Regulatory notices	9
TFT Displays	9
Water ingress	9
Disclaimer	9
Declaration of Conformity	9
PSTI Compliance	9
Product disposal	10
Warranty policy and registration	10
IMO and SOLAS	10
Technical accuracy	10
Publication copyright	10
CHAPTER 2 DOCUMENT INFORMATION	11
2.1 Applicable products	12
2.2 Product documentation	12
Operation instructions	12
2.3 Document illustrations	12
CHAPTER 3 PRODUCT AND SYSTEM OVERVIEW	13
3.1 Product overview	14
3.2 Compatible transducers	14
3.3 Software updates	14
3.4 Typical system	15
Expanded system	15
CHAPTER 4 PARTS SUPPLIED	17
4.1 Parts supplied	18
CHAPTER 5 PRODUCT DIMENSIONS	19
5.1 Product dimensions	20
CHAPTER 6 LOCATION REQUIREMENTS	21
6.1 Warnings and cautions	22
6.2 General location requirements	22
6.3 Compass safe distance	22
6.4 Viewing angle considerations	22
6.5 EMC installation guidelines	22
CHAPTER 7 MOUNTING PREPARATION	24
7.1 Tools required	25
7.2 Bezel removal	25
7.3 Removing the bezel	25
CHAPTER 8 MOUNTING	26
8.1 Mounting	27
CHAPTER 9 CABLES AND CONNECTIONS — GENERAL INFORMATION	28
9.1 General cabling guidance	29
Cable types and length	29
Cable routing and bend radius	29
Strain relief	29
Cable shielding	29
9.2 Connections overview	30
Connecting SeaTalk NG cables	30
SeaTalk NG product loading	30
9.3 Typical system	31

Expanded system	31	Fitting spade connectors to transducer wires	46
CHAPTER 10 POWER CONNECTION	33	Connecting transducers to legacy transducer pods	46
10.1 SeaTalk NG power supply	34	CHAPTER 13 OPERATION.....	48
10.2 Inline fuse requirement	34	13.1 Operation instructions	49
10.3 Inline fuse and thermal breaker ratings	34	CHAPTER 14 MAINTENANCE.....	50
10.4 12 Volt dc only	35	14.1 Service and maintenance	51
10.5 SeaTalk NG power cables	35	14.2 Routine equipment checks.....	51
10.6 SeaTalk NG power cable extension	35	14.3 Cleaning the display case.....	51
10.7 SeaTalk NG product loading	36	14.4 Cleaning the display screen	51
10.8 SeaTalk NG power connection point.....	36	Transducer cleaning	51
10.9 SeaTalk NG system loading.....	36	14.5 Cleaning the sun cover.....	51
10.10 Power distribution — SeaTalk NG.....	37	CHAPTER 15 TROUBLESHOOTING	52
10.11 12 Volt dc only.....	39	15.1 Troubleshooting	53
10.12 Positive ground systems	39	15.2 Power up troubleshooting	53
10.13 Product grounding.....	39	15.3 System data troubleshooting.....	54
10.14 Power connection via Autopilot Control Unit (ACU-Series).....	39	15.4 Miscellaneous troubleshooting	55
CHAPTER 11 NETWORK CONNECTIONS.....	41	15.5 Performing a Factory Reset	55
11.1 SeaTalk NG connection	42	CHAPTER 16 TECHNICAL SUPPORT	57
11.2 NMEA 2000 connection	42	16.1 Raymarine technical support and servicing	58
11.3 SeaTalk 1 connection	42	16.2 Checking hardware and software information	59
CHAPTER 12 TRANSDUCER CONNECTIONS.....	43	CHAPTER 17 TECHNICAL SPECIFICATION.....	60
12.1 Transducer connections	44	17.1 Power specification	61
12.2 RSW-Series transducer connection.....	44	17.2 Network specification	61
12.3 Smart transducer connection	44	17.3 Environmental specification	61
12.4 iTC-5 SeaTalk NG connections	45	17.4 Display specification.....	61
iTC-5 transducer connections	45		
12.5 Transducer pod connections	45		
Connecting legacy transducer pods to SeaTalk NG.....	46		

17.5 Conformance specification.....	61
CHAPTER 18 SPARES AND ACCESSORIES.....	62
18.1 Spares and accessories	63
18.2 Smart transducers.....	63
18.3 Instrument Depth, Speed and Temperature (DST) transducers	63
18.4 Instrument Depth transducers	64
18.5 Instrument Speed and Temperature transducers	65
18.6 RSW-Series transducers	65
18.7 Instrument Wind Vane transducer	65
18.8 Instrument Rotavecta transducer	66
18.9 Other transducers	66
18.10 SeaTalk NG cables and accessories.....	67
APPENDIX A SUPPORTED NMEA 2000 PGN LIST	71
APPENDIX B DOCUMENT CHANGE HISTORY	72

CHAPTER 1: IMPORTANT INFORMATION

Safety warnings



Warning: Product installation and operation

- This product must be installed and operated in accordance with the instructions provided. Failure to do so could result in personal injury or damage to your vessel. It may also cause poor product performance or invalidate the product warranty.

- Raymarine highly recommends certified installation by a Raymarine approved installer. A certified installation qualifies for enhanced product warranty benefits. Register your warranty on the Raymarine website: www.raymarine.com/warranty



Warning: Potential ignition source

This product is NOT approved for use in hazardous/flammable atmospheres. Do NOT install in a hazardous/flammable atmosphere (such as in an engine room or near fuel tanks).



Warning: Switch off power supply

Ensure that the vessel's power supply is switched OFF before starting to install this product. Do NOT connect or disconnect equipment with the power switched on, unless instructed to do so in this document.

Product warnings



Warning: Product grounding

Before applying power to this product, it **MUST** be correctly grounded, in accordance with the instructions provided.



Warning: Positive ground systems

Do NOT connect this unit to a system which has positive grounding.



Warning: Power supply voltage

Connecting this product to a voltage supply greater than the specified maximum rating may cause permanent damage to the unit. For the correct voltage, refer to the information label affixed to the product.

Caution: Power supply protection

When installing this product, ensure that the power source is adequately protected by means of a suitably-rated fuse or thermal circuit breaker.

Caution: Sun covers

- Sun covers are used to protect the display screen against the damaging effects of ultraviolet (UV) light. If your product is supplied with a sun cover always ensure it is fitted when the product is not in use.

- To avoid potential loss of the sun cover, ensure that the sun cover is removed when travelling at high speed, whether in the water or when the vessel is being towed.

- To avoid potential screen damage, ensure that the rear surface of the sun cover and the display screen are clean and free from debris before placing the sun cover on the screen.

Regulatory notices

TFT Displays

The colors of the display may seem to vary when viewed against a colored background or in colored light. This is a perfectly normal effect that can be seen with all color Thin Film Transistor (TFT) displays.

Water ingress

Water ingress disclaimer

Although the waterproof rating capacity of this product meets the stated water ingress protection standard (refer to the product's *Technical Specification*), water intrusion and subsequent equipment failure may occur if the product is not installed correctly or subjected to high-pressure washing. Raymarine will not warrant products subjected to high-pressure washing.

Disclaimer

Raymarine does not warrant that this product is error-free or that it is compatible with products manufactured by any person or entity other than Raymarine.

Raymarine is not responsible for damages or injuries caused by your use or inability to use the product, by the interaction of the product with products manufactured by others, or by errors in information utilized by the product supplied by third parties.

Third-party hardware, such as converters, adapters, routers, switches, Access Points etc., provided by third parties, may be made available directly to you by other companies or individuals under separate terms and conditions, including separate fees and charges. Raymarine UK Ltd or its affiliates have not tested or screened the third-party hardware.

Raymarine has no control over, and is not responsible for:

- (a) the content and operation of such third-party hardware; or
- (b) the privacy or other practices of such third-party hardware.

The fact that Raymarine's documentation may make reference to such third-party hardware does not indicate any approval or endorsement of any such third-party hardware. Raymarine may reference such third-party hardware only as a convenience.

THIS INFORMATION IS MADE AVAILABLE BY Raymarine ON THE BASIS THAT YOU EXCLUDE TO THE FULLEST EXTENT LAWFULLY PERMITTED ALL LIABILITY WHATSOEVER FOR ANY LOSS OR DAMAGE HOWSOEVER ARISING OUT OF THE USE OF THIS INFORMATION OR RELIANCE UPON THIS INFORMATION.

Raymarine does not exclude **Raymarine's** liability (if any) to you for personal injury or death resulting from **Raymarine UK Ltd** negligence, for fraud or for any matter which it would be illegal to exclude or to attempt to exclude.

Declaration of Conformity

Raymarine UK Ltd declares that the products listed below are in conformity with the relevant sections of the listed designated standards and / or other normative documents:

- **i70** — E22172

Region	Standard	Mark
UK	EMC Regulations 2016	
EU	EMC Directive 2014/30/EU	

The original Declaration of Conformity certificate may be viewed at: www.bit.ly/i70-docs

PSTI Compliance

For products sold into the United Kingdom (UK), use the following link to obtain the product's Statement of Compliance with the *Product Security and Telecommunications Infrastructure* (PSTI) Regulations:


Visit the following web address and enter the product's model name or number (SKU) into the provided search field:

- www.bit.ly/rym-sec-com

Product disposal

Dispose of this product in accordance with the WEEE Directive.

The Waste Electrical and Electronic Equipment (WEEE) Directive requires the recycling of waste electrical and electronic equipment which contains materials, components and substances that may be hazardous and present a risk to human health and the environment when WEEE is not handled correctly.



Equipment marked with the crossed-out wheeled bin symbol indicates that the equipment should not be disposed of in unsorted household waste. Local authorities in many regions have established collection schemes under which residents can dispose of waste electrical and electronic equipment at a recycling center or other collection point. For more information about suitable collection points for waste electrical and electronic equipment in your region, refer to the Raymarine website: <https://bit.ly/rym-recycling>

Warranty policy and registration

Visit the Raymarine website to **read the latest warranty policy**, and **register** your product's warranty online: www.bit.ly/rym-warranty

It is important that you register your product to receive full warranty benefits. Your product package includes a barcode label indicating the serial number of the unit. This serial number is also provided on a label affixed to the product itself. You will need this serial number when registering your product online.

IMO and SOLAS

The equipment described within this document is intended for use on leisure marine boats and workboats NOT covered by International Maritime Organization (IMO) and Safety of Life at Sea (SOLAS) Carriage Regulations.

Technical accuracy

To the best of our knowledge, the information in this document was correct at the time it was produced. However, Raymarine cannot accept liability for any inaccuracies or omissions it may contain. In addition, our policy of continuous product improvement may

change specifications without notice. As a result, Raymarine cannot accept liability for any differences between the product and this document. Please check the Raymarine website to ensure you have the most up-to-date version(s) of the documentation for your product: www.docs.raymarine.com

Publication copyright

Copyright ©2025 Raymarine UK Ltd. All rights reserved. No parts of this material may be copied, translated, or transmitted (in any medium) without the prior written permission of Raymarine UK Ltd.

CHAPTER 2: DOCUMENT INFORMATION

CHAPTER CONTENTS

- 2.1 Applicable products — page 12
- 2.2 Product documentation — page 12
- 2.3 Document illustrations — page 12

2.1 Applicable products

This document is applicable to the following products:

i70 (E22172) — Multifunctional instrument display.

2.2 Product documentation

The following documentation is applicable to your product:

This and other Raymarine product documents are available to view or download at www.bit.ly/rym-docs

i70 documentation

Description	Part number
i70 Multifunction Instrument Display Installation Instructions (this document)	87425
i70s / i70 Operation Instructions	81401
i70 Mounting Template	87130

Additional documentation

Description	Part number
SeaTalk NG Reference Manual	81300
iTC-5 Installation Instructions	87138

Operation instructions

For operation instructions, please refer to the i70 / i70s Operation Instructions (81401).

Document	Number	Link
i70 / i70s <i>Operation Instructions</i>	81401	www.bit.ly/i70-docs

2.3 Document illustrations

Your product and if applicable, its user interface may differ slightly from that shown in the illustrations in this document, depending on product variant and date of manufacture.

All images are provided for illustration purposes only.

CHAPTER 3: PRODUCT AND SYSTEM OVERVIEW

CHAPTER CONTENTS

- 3.1 Product overview — page 14
- 3.2 Compatible transducers — page 14
- 3.3 Software updates — page 14
- 3.4 Typical system — page 15

3.1 Product overview

The i70 is a multifunctional instrument display. In conjunction with compatible instrument transducers and an iTC-5, the i70 provides a detailed view of environmental, navigational and vessel data.



The i70 has the following features:

- 4.1" high brightness color LCD with wide viewing angles.
- Can be connected to SeaTalk NG, NMEA 2000 and SeaTalk 1.
- All weather optically bonded LCD.
- Large clear characters (up to 43 mm / 1.7 in) for easy reading in any conditions.
- Easy to use operating system.
- Display of AIS targets.
- Data views include: Wind, Speed, Depth, Tridata, Engine, Environment, Fuel and Navigation.
- 12 V dc operation.
- Low power consumption.
- Waterproof to IPx6.

3.2 Compatible transducers

For a list of compatible transducers, please refer to:

[p.62 — Spares and accessories](#)

3.3 Software updates

Raymarine regularly issues software updates for its products, which provide new and enhanced features and improved performance and usability. It's important to ensure that you have the latest software for your products by regularly checking the Raymarine website for new software releases.

To check for the latest software updates and the software update procedure for your specific product(s), refer to:

www.bit.ly/rym-software

Unless otherwise stated, software updates for Raymarine products are performed using a Raymarine MFD / chartplotter.

- Where applicable, you should always backup your user data and settings before performing a software update.
- To update SeaTalk NG products, you must use the datamaster MFD / chartplotter which is physically connected to the SeaTalk NG backbone.
- Ethernet (RayNet) products can be updated from any MFD / chartplotter on the same network as the product to be updated.
- In order to perform a software update, any connected Autopilot or Radar must be switched to Standby.
- The MFD / chartplotter "Check online" feature is only available when connected to the Internet.

Note:

If in doubt as to the correct procedure for updating your product software, refer to your dealer or Raymarine technical support.

Caution: Installing software updates

- The software update process is carried out at your own risk. Before initiating the update process ensure you have backed up any important files.
- Ensure that the product(s) has a reliable power supply and that the update process is not interrupted.
- Damage caused by an incomplete update is not covered by Raymarine warranty.
- By downloading the software update package, you agree to these terms.


3.4 Typical system

The following illustration shows an example of an i70 SeaTalk NG system.

Note:

This system is shown as an example only and may differ from your planned installation.


Example: Simple environmental data system



1. i70 Instrument display.
2. SeaTalk NG spur cable.
3. SeaTalk NG T-piece connector with Terminator fitted.
4. Wind transducer (Analog).
5. SeaTalk NG backbone cable.
6. iTC-5 with terminator fitted.
7. SeaTalk NG power cable.
8. 5 amp fuse in waterproof fuse holder.
9. Depth transducer (Analog).
10. Speed / Temperature transducer (Analog).
11. 12 V dc power supply.

Expanded system

Example: Expanded system



1. AIS dedicated GNSS (GPS) receiver.
2. VHF antenna.
3. SeaTalk NG Pilot controller (e.g.: p70R).
4. MFD (e.g.: Axiom+ 7).
5. i70 instrument display.
6. GNSS (GPS) receiver (e.g.: RS150).
7. AIS receiver / transceiver (e.g.: AIS700).
8. Evolution autopilot (e.g.: EV-1).
9. iTC-5.
10. Autopilot control unit (e.g.: ACU-400).
11. ECI-100.
12. Vessel / Engine systems.
13. Depth transducer (Analog).
14. Wind transducer (Analog).
15. Speed / Temperature transducer (Analog).

16. 12 V dc / 24 V dc power supply (supplying 12 V dc to the SeaTalk NG backbone via the ACU).
17. Rudder reference transducer.

Note:

Depending on engine type, it may be possible to connect the engine system directly to the SeaTalk NG backbone using a SeaTalk NG to DeviceNet adaptor cable. However the data available will be restricted to supported, standard NMEA 2000 data only.

CHAPTER 4: PARTS SUPPLIED


CHAPTER CONTENTS

- [4.1 Parts supplied — page 18](#)

4.1 Parts supplied

The following parts are supplied with your product.

Unpack the unit carefully to prevent damage. Save the carton and packing in case the unit has to be returned for service.



1. Suncover (Part No.: R22169)
2. Bezel (Part No.: R22168)
3. SeaTalk NG spur cable 400 mm (15.7 in) (Part No.: A06038)
4. Documentation pack
5. i70 instrument display.
6. Panel seal gasket
7. SeaTalk NG blanking plug.
8. 4 x M3x16 pan head pozi mounting screws


CHAPTER 5: PRODUCT DIMENSIONS

CHAPTER CONTENTS

- [5.1 Product dimensions — page 20](#)

5.1 Product dimensions

Product dimensions are shown below.



Dimensions

A	110 mm (4.33 in)
B	115 mm (4.53 in)
C	14.05 mm (0.55 in)
D	29.80 mm (1.17 in)
E	80.00 mm (3.15 in)
F	90.00 mm (3.54")
G	17.00 mm (0.67")

CHAPTER 6: LOCATION REQUIREMENTS

CHAPTER CONTENTS

- 6.1 Warnings and cautions — page 22
- 6.2 General location requirements — page 22
- 6.3 Compass safe distance — page 22
- 6.4 Viewing angle considerations — page 22
- 6.5 EMC installation guidelines — page 22

6.1 Warnings and cautions

Important:

Before proceeding, ensure that you have read and understood the warnings and cautions provided in the following section of this document:

- [p.8 — Important information](#)

6.2 General location requirements

Below are important requirements that need to be considered when choosing a suitable location to install your product.

The product is suitable for mounting above or below decks.

The product should be mounted in a location where it will be:

- Protected from physical damage and excessive vibration.
- Well ventilated and away from heat sources.
- Away from any potential ignition source such as an engine room, near fuel tanks or a gas locker.
- Easily accessible for operations.

When choosing a location for the product, consider the following to ensure reliable and trouble-free operation:

- Access — there must be sufficient space to enable cable connections and to avoid tight cable bends.
- Electrical interference — the product should be mounted far enough away from any equipment that may cause interference such as engines, motors, generators, radio transmitters / receivers and cables carrying high power.
- Magnetic compass — refer to the *Compass safe distance* section in this document for advice on maintaining a suitable distance between this product and any compasses on your vessel.
- Mounting surface — ensure the product is adequately supported on a secure surface. Refer to the weight information provided in the *Technical specification* for this product and ensure that the intended mounting surface is suitable for bearing the product weight. Do NOT mount units or cut holes in places which may damage the structure of the vessel.

6.3 Compass safe distance

To prevent potential interference with the vessel's magnetic compasses, ensure an adequate distance is maintained from the product.

When choosing a suitable location for the product you must aim to maintain a distance of at least 1 m (3.3 ft) in all directions from any compasses.

For some smaller vessels it may not be possible to locate the product this far away from a compass. In this situation, when choosing the installation location for your product, ensure that the compass is not affected by the product when it is in a powered on state.

6.4 Viewing angle considerations

As display contrast and color are affected by the viewing angle, it is recommended that you temporarily power up the display, prior to installation, to enable you to best judge which location provides the optimum viewing angle.

For viewing angles for your product refer to the *Technical specification*.

6.5 EMC installation guidelines

Raymarine equipment and accessories conform to the appropriate Electromagnetic Compatibility (EMC) regulations, to minimize electromagnetic interference between equipment and minimize the effect such interference could have on the performance of your system.

Correct installation is required to ensure that EMC performance is not compromised.

Note:

In areas of extreme EMC interference, some slight interference may be noticed on the product. Where this occurs the product and the source of the interference should be separated by a greater distance.

For **optimum** EMC performance we recommend that wherever possible:

- Raymarine equipment and cables connected to it are:
 - At least 1 m (3.28 ft) from any equipment transmitting or cables carrying radio signals e.g. VHF radios, cables and antennas. In the case of SSB radios, the distance should be increased to 2 m (6.6 ft).
 - More than 2 m (6.56 ft) from the path of a radar beam. A radar beam can normally be assumed to spread 20 degrees above and below the radiating element.
- The product is supplied from a separate battery from that used for engine start. This is important to prevent erratic behavior and data loss which can occur if the engine start does not have a separate battery.
- Raymarine specified cables are used.
- Cables are not cut or extended, unless doing so is detailed in the installation manual.

Note:

Where constraints on the installation prevent any of the above recommendations, always ensure the maximum possible separation between different items of electrical equipment, to provide the best conditions for EMC performance throughout the installation.


CHAPTER 7: MOUNTING PREPARATION

CHAPTER CONTENTS

- [7.1 Tools required — page 25](#)
- [7.2 Bezel removal — page 25](#)
- [7.3 Removing the bezel — page 25](#)

7.1 Tools required

The following tools are required to install your product.




1. Power drill
2. 92 mm (3 5/8 in) Hole cutter
3. Adhesive tape
4. Drill bit of appropriate size for mounting fixings⁽¹⁾
5. Pozi drive screwdriver
6. Plastic pry tool
7. File

Note:

(1) Drill bit size is dependent on the thickness and type of material that the product is to be mounted on.

7.2 Bezel removal



7.3 Removing the bezel

Instructions for removing the display's bezel.

Note:

Take care when removing the bezel. Only use a plastic pry tool (not supplied) to lever the bezel; attempting to use a metal tool may cause damage to the unit.

1. Using a plastic pry tool and your fingers, pry the bezel away from the display at the top and on one side of the display.
You should hear a click as each side of the bezel is released.
2. Pry the bezel away from the display on the opposite side.
3. The entire bezel can now be pulled away from the display.

CHAPTER 8: MOUNTING

CHAPTER CONTENTS


- [8.1 Mounting — page 27](#)

8.1 Mounting

Follow the instructions below to mount the display.

Before mounting the product, ensure that you have:

- Selected a suitable location, based on the location requirements found in this document. For more information, refer to: [p.21 — Location requirements](#)
- Identified the relevant cable connections and the route that the cables will take.
- Removed the bezel and button pad from the display.



1. Apply the supplied mounting template to the selected location, using self adhesive tape.
2. Drill the cut-out hole using a 92 mm (3 5/8") hole cutter.
Alternatively, use a small drill bit to make pilot holes in each corner of the cut-out area, and then use a jigsaw to cut along the inside edge of the cut-out line.
3. Ensure that the display fits into the removed area.
4. File around any rough edges.
5. Drill the fixing holes as indicated on the mounting template.

6. Peel the backing off of the panel mounting gasket, place the adhesive side of the gasket onto the back of the display, and then press firmly onto the flange.
7. Connect the SeaTalk NG cable.
8. Position the display in place and secure using the fixings provided.
9. Re-fit the button pad and bezel.

Note:

- Drill bit, tap size, and tightening torques are dependant upon the material type and thickness of the mounting surface.
- The supplied gasket provides a seal between the unit and a suitably flat and stiff mounting surface or binnacle. The gasket should be used in all installations. If the mounting surface or binnacle is not entirely flat and stiff or has a rough surface finish, it may also be necessary to use a marine-grade sealant.

CHAPTER 9: CABLES AND CONNECTIONS — GENERAL INFORMATION

CHAPTER CONTENTS

- [9.1 General cabling guidance — page 29](#)
- [9.2 Connections overview — page 30](#)
- [9.3 Typical system — page 31](#)

9.1 General cabling guidance

Cable types and length


It is important to use cables of the appropriate type and length.

- Unless otherwise stated only use cables supplied by Raymarine.
- Where it is necessary to use non-Raymarine cables, ensure that they are of correct quality and gauge for their intended purpose. (e.g.: longer power cable runs may require larger wire gauges to minimize voltage drop along the run).

Cable routing and bend radius

To maximize cable performance and lifespan, it's important to ensure that all cables are routed correctly and adequate space is provided to allow for each cable's minimum bend radius.

Minimum cable bend radius



Do NOT bend cables excessively. Wherever possible, ensure that your chosen product installation location allows enough clearance for the minimum cable bend diameter specified in the following table:

	Description	Value
Ø	Cable minimum bend diameter .	200 mm (7.87 in.)
R	Cable minimum bend radius .	100 mm (3.94 in.)

Note:

For products where multiple different cable types are connected, each with a different minimum cable bend radius, the higher figure is provided in the table above (i.e. the cable with the greatest minimum bend radius is specified).

Cable routing — best practices

- Protect all cables from physical damage and exposure to heat. Use trunking or conduit where possible. Do NOT run cables through bilges or doorways, or close to moving or hot objects.
- Secure cables in place using cable clips or cable ties. Coil any excess cable and tie it out of the way.
- Where a cable passes through an exposed bulkhead or deckhead, use a suitable watertight feed-through (conduit).
- Do NOT run cables near to engines or fluorescent lights.
- Always route data cables as far away as possible from:
 - Other equipment and cables.
 - High current-carrying AC and DC power lines.
 - Antennas.

Strain relief

Use adequate strain relief for cabling to ensure that connectors are protected from strain and will not pull out under extreme sea conditions.

Cable shielding


Ensure that cable shielding is not damaged during installation and that all cables are properly shielded.

Important:

Be aware that some **third-party** cables and adaptors (for example, certain Ethernet cables using RJ45 connectors) are not always shielded. To prevent breaks in cable shielding continuity and potential grounding issues, special attention is required to ensure that any cables, extension cables, adaptors, or other signal-coupling devices (such as multi-way connectors, junction boxes, terminal blocks etc.) used in cable runs **maintain all shield connections throughout the cable run**.


9.2 Connections overview

Your product is supplied power and data using the SeaTalk NG connector located on the rear of the unit.

Connector	Connection options
	<ul style="list-style-type: none">• SeaTalk NG backbone using a SeaTalk NG spur cable.• NMEA 2000 backbone using SeaTalk NG to DeviceNet adaptor cable (A06045)• SeaTalk 1 backbone using a SeaTalk 1 to SeaTalk NG adaptor cable (A06073)

For a list of available cables, refer to: [p.62 — Spares and accessories](#)

Connecting SeaTalk NG cables



1. Rotate your product's SeaTalk NG connector locking collar counter clockwise, so that the connector is in the unlocked position.
2. Ensure the cable's connector is correctly oriented (groove pointing up).
3. Fully insert the cable connector.
4. Rotate the locking collar clockwise (2 clicks) until it is in the locked position.

SeaTalk NG product loading

The number of products that can be connected to a SeaTalk NG backbone depends on the current draw of each product and the physical length of the backbone cabling.

NMEA 2000 Load Equivalency Numbers (LEN) are used to express the amount of current that is drawn from SeaTalk NG products (**1 LEN = 50 mA**). The LEN for each product can be found in the product's *Technical Specification*.

Products which have a dedicated power supply connection and are connected to the SeaTalk NG backbone will still have an LEN rating. This is because the product's NMEA 2000 / SeaTalk NG internal transceiver will still be powered by the SeaTalk NG backbone.

LENs are used to determine the power connection point for the SeaTalk NG backbone.


9.3 Typical system

The following illustration shows an example of an i70 SeaTalk NG system.

Note:

This system is shown as an example only and may differ from your planned installation.


Example: Simple environmental data system



1. i70 Instrument display.
2. SeaTalk NG spur cable.
3. SeaTalk NG T-piece connector with Terminator fitted.
4. Wind transducer (Analog).
5. SeaTalk NG backbone cable.
6. iTC-5 with terminator fitted.
7. SeaTalk NG power cable.
8. 5 amp fuse in waterproof fuse holder.
9. Depth transducer (Analog).
10. Speed / Temperature transducer (Analog).
11. 12 V dc power supply.

Expanded system

Example: Expanded system



1. AIS dedicated GNSS (GPS) receiver.
2. VHF antenna.
3. SeaTalk NG Pilot controller (e.g.: p70R).
4. MFD (e.g.: Axiom+ 7).
5. i70 instrument display.
6. GNSS (GPS) receiver (e.g.: RS150).
7. AIS receiver / transceiver (e.g.: AIS700).
8. Evolution autopilot (e.g.: EV-1).
9. iTC-5.
10. Autopilot control unit (e.g.: ACU-400).
11. ECI-100.
12. Vessel / Engine systems.
13. Depth transducer (Analog).
14. Wind transducer (Analog).
15. Speed / Temperature transducer (Analog).

16. 12 V dc / 24 V dc power supply (supplying 12 V dc to the SeaTalk NG backbone via the ACU).
17. Rudder reference transducer.

Note:

Depending on engine type, it may be possible to connect the engine system directly to the SeaTalk NG backbone using a SeaTalk NG to DeviceNet adaptor cable. However the data available will be restricted to supported, standard NMEA 2000 data only.

CHAPTER 10: POWER CONNECTION

CHAPTER CONTENTS

- 10.1 SeaTalk NG power supply — page 34
- 10.2 Inline fuse requirement — page 34
- 10.3 Inline fuse and thermal breaker ratings — page 34
- 10.4 12 Volt dc only — page 35
- 10.5 SeaTalk NG power cables — page 35
- 10.6 SeaTalk NG power cable extension — page 35
- 10.7 SeaTalk NG product loading — page 36
- 10.8 SeaTalk NG power connection point — page 36
- 10.9 SeaTalk NG system loading — page 36
- 10.10 Power distribution — SeaTalk NG — page 37
- 10.11 12 Volt dc only — page 39
- 10.12 Positive ground systems — page 39
- 10.13 Product grounding — page 39
- 10.14 Power connection via Autopilot Control Unit (ACU-Series) — page 39

10.1 SeaTalk NG power supply

Your product is supplied power via the SeaTalk NG backbone (or the NMEA 2000 backbone if applicable).

A SeaTalk NG backbone requires a single 12 V dc power supply. Power can be supplied to the SeaTalk NG backbone by one of the following methods:

- ⁽¹⁾ Direct connection to a 12 V dc battery using an inline 5 amp fuse.
- Connection to a 12 V dc distribution panel using a 3 amp thermal breaker.
- ⁽²⁾ Connection to the SeaTalk NG connector of an ACU-Series Autopilot Control Unit (not ACU-100 or ACU-150), or an SPX-Series course computer (not SPX-5).
- For 24 V vessels, connection must be via a 5 amp, regulated, continuous 24 V dc to 12 V dc converter.

Note:


- ⁽¹⁾ The battery used for starting the vessel's engine(s) should NOT be used to power the SeaTalk NG backbone, as this can cause sudden voltage drops when the engines are started.
- ⁽²⁾ The ACU-100, ACU-150 or SPX-5 cannot be used to power the SeaTalk NG backbone.
- The course computer SeaTalk NG connector includes a power switch that must be in the On position to provide power to the backbone.

10.2 Inline fuse requirement

If your product is NOT supplied with an inline fuse (whether separately or fitted to the power cable), you MUST fit a suitably-rated inline fuse to your product's red power wire, housed in a waterproof fuse holder.

The illustration below shows the two main types of inline fuse with waterproof holder, for use in marine electronics installations. Fuses in a variety of ratings are widely available at chandleries and marine electrical retailers.

Select one of the following fuse types to protect your product:



1. Waterproof fuse holder containing a “glass”-type inline fuse.
2. Waterproof fuse holder containing a “blade”-type inline fuse.

Fuse ratings:

- *Voltage rating* — must be equal to or greater than the voltage of your vessel's power supply.
- *Current rating* — refer to the *Inline fuse and thermal breaker rating* section in this document.

10.3 Inline fuse and thermal breaker ratings

The SeaTalk NG network's power supply requires a suitably-rated inline fuse or thermal breaker to be fitted.

Inline fuse rating	Thermal breaker rating
5A	3A (refer to note below)

Note:

The suitable fuse rating for the thermal breaker is dependent on:

1. How many devices you have connected to your SeaTalk NG network, and;
2. How many devices are sharing the same thermal breaker that your SeaTalk NG network is connected to.


10.4 12 Volt dc only

This product must **ONLY** be connected to a 12 V dc power source.

10.5 SeaTalk NG power cables

The following SeaTalk NG power cables can be used to connect the backbone to your chosen **12 V dc** power supply:

Direct connection cables



1. Standard (straight) SeaTalk NG power cable, 2 m (6.6 ft) (part number: **A06049**).
2. Elbow (right-angled) SeaTalk NG power cable, 2 m (6.6 ft) (part number: **A06070**).

Wiring

- **+ Red (positive) wire** — connects to the battery or distribution panel positive terminal. A waterproof fuse holder with 5 A inline fuse (not supplied) must be fitted to this red wire.
- **– Black (negative) wire** — connects to battery or distribution panel negative terminal.
- **Drain wire** — connects to the vessel's RF common ground point (if available), or the battery's negative (-) terminal.

Autopilot Control Unit connection cable



1. ACU-Series/SPX-Series autopilot to SeaTalk NG spur cable, 0.3 m (1.0 ft) (part number **R12112**). Connects the course computer to the SeaTalk NG backbone. This connection can also be used to provide 12 V dc power to the SeaTalk NG backbone.

10.6 SeaTalk NG power cable extension

If you need to extend the length of the SeaTalk NG power cable, ensure you observe the following advice:

- Ensure that any extensions of the SeaTalk NG power cable are of a sufficient gauge for the supply voltage, the total current load of the device, and the length of the cable run — as the cable run length increases, the greater the voltage drop will be from one end of the power cable to the other.
- Refer to the following table for typical **minimum** power cable wire gauges:

Cable length in meters (feet)	Wire gauge in AWG (mm ²) for 12 V supply
<8 (<25)	16 (1.31 mm ²)
16 (50)	14 (2.08 mm ²)
24 (75)	12 (3.31 mm ²)
>32 (>100)	10 (5.26 mm ²)

Important:

Be aware that some products in your system (such as sonar modules) can create voltage peaks at certain times, which may impact the voltage available to other products during the peaks.

Important:

To ensure power cables (including any extension) are of a sufficient gauge, ensure that there is a continuous **minimum** voltage of **10.8 V dc** at the end of the SeaTalk NG power cable where it enters the SeaTalk NG backbone, even with a fully flat battery at 11 V dc. (Do not assume that a flat battery is at 0 V dc. Due to the discharge profile and internal chemistry of batteries, the current drops much faster than the voltage. A “fully flat” battery still shows a positive voltage, even if it doesn't have enough current to power your device.)

10.7 SeaTalk NG product loading

The number of products that can be connected to a SeaTalk NG backbone depends on the current draw of each product and the physical length of the backbone cabling.

NMEA 2000 Load Equivalency Numbers (LEN) are used to express the amount of current that is drawn from SeaTalk NG products (**1 LEN = 50 mA**). The LEN for each product can be found in the product's *Technical Specification*.

Products which have a dedicated power supply connection and are connected to the SeaTalk NG backbone will still have an LEN rating. This is because the product's NMEA 2000 / SeaTalk NG internal transceiver will still be powered by the SeaTalk NG backbone.

LENs are used to determine the power connection point for the SeaTalk NG backbone.

10.8 SeaTalk NG power connection point

The point along the backbone where the power connection should be made is based on the length of the backbone.

Note:


- A 12 V dc power supply must be connected to a *white* spur SeaTalk NG connection on the backbone.
- Do NOT connect the power connection to a *blue* SeaTalk NG backbone connector.
- **With the exception of** the iTC-5 and the backbone itself, do NOT connect the power supply directly to a product's *white* SeaTalk NG spur connector.

Small systems

If the backbone length is 60 m (197 ft) or less, the power connection may be made at any point in the backbone.

Large systems

If the backbone length is greater than 60 m (197 ft), the power connection should be made at a point that creates a balanced current draw from each side of the backbone. Load Equivalency Numbers (LEN) are used to determine the power connection point for the system.



In the example above, the system has an overall LEN of 16, so the optimum connection point would be to have a loading of 8 LEN either side of the connection point.

10.9 SeaTalk NG system loading

The maximum loading (LEN) for a SeaTalk NG system depends on the length of the backbone.

Unbalanced system loading:

- **Backbone Length:** 0 m (0 ft) to 20 m (66 ft) — **Maximum LEN:** 40
- **Backbone Length:** > 20 m (66 ft) to 40 m (131 ft) — **Maximum LEN:** 20
- **Backbone Length:** > 40 m (131 ft) to 60 m (197 ft) — **Maximum LEN:** 14

Balanced system loading:

- **Backbone Length:** 0 m (0 ft) to 60 m (197 ft) — **Maximum LEN:** 100
- **Backbone Length:** > 60 m (197 ft) to 80 m (262 ft) — **Maximum LEN:** 84
- **Backbone Length:** > 80 m (262 ft) to 100 m (328 ft) — **Maximum LEN:** 60
- **Backbone Length:** > 100 m (328 ft) to 120 m (394 ft) — **Maximum LEN:** 50

- **Backbone Length:** > 120 m (394 ft) to 160 m (525 ft) — **Maximum LEN: 40**
- **Backbone Length:** > 160 m (525 ft) to 200 m (656 ft) — **Maximum LEN: 32**

10.10 Power distribution — SeaTalk NG


Recommendations and best practice.

- Only use approved SeaTalk NG power cables. Do NOT use a power cable designed for, or supplied with, a different product.
- See below for more information on implementation for some common power distribution scenarios.


Important:

- When planning and wiring, take into consideration other products in your system, some of which (e.g. sonar modules) may place large power demand peaks on the vessel's electrical system, which may impact the voltage available to other products during the peaks.
- The information provided below is for guidance only, to help protect your product. It covers common vessel power arrangements, but does NOT cover every scenario. If you are unsure how to provide the correct level of protection, please consult an authorized Raymarine dealer or a suitably qualified professional marine electrician.

Implementation — connection to distribution panel (recommended)



1. Waterproof fuse holder with 5 A inline fuse must be fitted (not supplied).
 2. SeaTalk NG power cable.
 3. RF Ground connection point for drain wire.
- Ideally, the SeaTalk NG power cable should be connected to a suitable breaker or switch on the vessel's distribution panel or factory-fitted power distribution point. It is recommended that a 5 A inline fuse is fitted to the red (positive) wire of the SeaTalk NG power cable.
 - The distribution point should be fed from the vessel's primary power source by 8 AWG (8.36 mm²) cable.
 - Ideally, all equipment should be wired to individual suitably-rated thermal breakers or fuses, with appropriate circuit protection. Where this is not possible and more than one item of equipment shares a breaker, use individual in-line fuses for each power circuit to provide the necessary protection.




1. Positive (+) bar
2. Negative (-) bar
3. Circuit breaker
4. Waterproof fuse holder with 5 A inline fuse must be fitted (not supplied).

Important:

Observe the recommended fuse / breaker ratings provided in the product's documentation, however be aware that the suitable fuse / breaker rating is dependent on the number of devices being connected.

Implementation — direct connection to battery

- Where connection to a power distribution panel is not possible, the power cable may be connected to the vessel's battery.
- You **MUST** fit a 5 A inline fuse between the red wire and the battery's positive terminal.
- If you need to extend the length of the power cable, ensure you use suitably rated cable and that sufficient power (12 V dc) is available at the SeaTalk NG backbone's power connection.



1. Waterproof fuse holder with 5 A inline fuse must be fitted (not supplied).
2. SeaTalk NG power cable.
3. Connection point for drain wire.

Battery connection scenario A:

Suitable for a vessel with a common RF ground point. In this scenario, the power cable's drain wire should be connected to the vessel's common RF ground point.

Battery connection scenario B:

Suitable for a vessel without a common RF ground point. In this scenario the power cable's drain wire should be connected directly to the battery's negative terminal.

SeaTalk NG Power cable extension

If you need to extend the length of the SeaTalk NG power cable, ensure you use suitably-rated cable, and that sufficient power is available at the SeaTalk NG backbone's power connection point:

- For power cable extensions, a **minimum** wire gauge of 16 AWG (1.31 mm²) is recommended. For cable runs longer than 15 m (49.2 ft), you may need to consider a thicker wire gauge (e.g. 14 AWG (2.08 mm²), or 12 AWG (3.31 mm²).

- To ensure power cables (including any extension) are of a sufficient gauge, ensure that there is a continuous **minimum** voltage of **10.8 V dc** at the end of the cable where it enters the product's power connector, even with a fully flat battery at 11 V dc. (Do not assume that a flat battery is at 0 V dc. Due to the discharge profile and internal chemistry of batteries, the current drops much faster than the voltage. A "fully flat" battery still shows a positive voltage, even if it doesn't have enough current to power your device.)

Important:

Be aware that some products in your system (such as sonar modules) can create voltage peaks at certain times, which may impact the voltage available to other products during the peaks.

More information

It is recommended that best practice is observed in all vessel electrical installations, as detailed in the following standards:

- BMEA Code of Practice for Electrical and Electronic Installations in Boats
- NMEA 0400 Installation Standard
- ISO 13297: Small craft — Electrical systems — Alternating and direct current installations
- ISO 10133: Small craft — Electrical systems — Extra-low-voltage d.c. installations
- ABYC E-11 AC & DC Electrical Systems on Boats
- ABYC A-31 Battery chargers and Inverters
- ABYC TE-4 Lightning Protection

10.11 12 Volt dc only

This product must **ONLY** be connected to a 12 V dc power source.

10.12 Positive ground systems

Do **NOT** connect this unit to a system which has positive grounding.

10.13 Product grounding

Important safety information for connections to ground.

Before applying power to this product, it **MUST** be correctly grounded, in accordance with the instructions provided.

10.14 Power connection via Autopilot Control Unit (ACU-Series)


The SeaTalk NG backbone can be supplied 12 V dc power from a compatible Raymarine Autopilot Control Unit (ACU-Series).

Important:

The SeaTalk NG backbone must have a single power supply connection. If your SeaTalk NG backbone is supplied power directly from a battery or distribution panel, then you must ensure that the SeaTalk NG power switch on your ACU-Series is switched Off.

Note:

ACU-100, ACU-150 and SPX-5 autopilot control units cannot supply power to the SeaTalk NG backbone.



1. Fuse for SeaTalk NG power supply.
2. Power switch for SeaTalk NG power supply:
 - a. Select the *[OFF]* position if your SeaTalk NG backbone is supplied power directly from a battery or distribution panel.
 - b. Select the *[ON]* position if your SeaTalk NG backbone is supplied power by the ACU-Series.
3. ACU-Series/SPX-Series autopilot to SeaTalk NG spur cable (part number: R12112).


CHAPTER 11: NETWORK CONNECTIONS

CHAPTER CONTENTS

- [11.1 SeaTalk NG connection — page 42](#)
- [11.2 NMEA 2000 connection — page 42](#)
- [11.3 SeaTalk 1 connection — page 42](#)

11.1 SeaTalk NG connection


The product can be connected to a SeaTalk NG backbone using the supplied spur cable.



1. i70 multifunction instrument display.
2. SeaTalk NG spur cable (400 mm (15.7 in) cable is supplied).
3. SeaTalk NG backbone.

11.2 NMEA 2000 connection


The product can be connected to a NMEA 2000 backbone using a SeaTalk NG to DeviceNet adaptor cable.



1. i70 multifunction instrument display.
2. SeaTalk NG to DeviceNet adaptor cable (e.g.: part A06075).
3. DeviceNet T-piece connector.

11.3 SeaTalk 1 connection

The display can be connected to a SeaTalk 1 network using a SeaTalk 1 to SeaTalk NG adaptor cable.



1. SeaTalk NG device (e.g.: i70)
2. SeaTalk 1 to SeaTalk NG adaptor cable i.e.: A06073 or A06047

CHAPTER 12: TRANSDUCER CONNECTIONS

CHAPTER CONTENTS

- [12.1 Transducer connections — page 44](#)
- [12.2 RSW-Series transducer connection — page 44](#)
- [12.3 Smart transducer connection — page 44](#)
- [12.4 iTC-5 SeaTalk NG connections — page 45](#)
- [12.5 Transducer pod connections — page 45](#)

12.1 Transducer connections

Transducers must be on the same SeaTalk NG backbone as the display.


Transducers can be connected using either an iTC-5 or legacy transducer pods. Smart transducers can be connected directly to the SeaTalk NG backbone.

12.2 RSW-Series transducer connection

The i70 instrument display can show wind data transmitted from the RSW-Series transducers.

The display must be on the same NMEA 2000/SeaTalk NG as the RSW-Series transducer.

System example



1. RSW-Series transducer.
2. GNSS (GPS) receiver (e.g.: RS150).
3. Heading sensor (e.g.: EV-1).

4. NMEA 2000 gateway (supplied with the RSW-Series transducer).
5. i70 instrument display, running software version v3.23 or later.
6. Alpha-Series displays.
7. SeaTalk NG 12 V dc power connection.
8. Speed transducer (e.g.: DST800).
9. MFD/Charplotter (e.g.: Axiom 2 Pro), running LightHouse 4 v4.5.84 or later.


Note:

- In order for your display to calculate and display True wind values, Speed Through Water (STW) (received from a speed transducer) and Heading (received from a heading sensor) data must be available.
- In order for your display to calculate and display Ground wind values a GNSS receiver is required.

For RSW-Series transducer installation and connection details refer to the documentation for your RSW-Series transducer.

12.3 Smart transducer connection

Smart transducers can be connected directly to the SeaTalk NG backbone without the need for an iTC-5 or transducer pod.



1. Smart transducer (e.g.: DST810).

- SeaTalk NG backbone.

12.4 iTC-5 SeaTalk NG connections

The iTC-5 converter connects inline with the SeaTalk NG backbone, and includes a spur connector to enable connection of another SeaTalk NG device to the backbone.

SeaTalk NG backbone connectors

The SeaTalk NG backbone connectors enable the converter to be connected inline as part of the SeaTalk NG backbone.

SeaTalk NG spur connector


The spur connector enables connection of another SeaTalk NG device, or connection to a suitable 12 V dc power supply.

Note:

Do NOT connect the spur connector to another spur connection on the backbone.

iTC-5 transducer connections

Analog transducer data can be transmitted to the display via an iTC-5.



- Speed & Temperature transducer connections
- Wind transducer connections
- Compass connections
- Rudder reference transducer connections
- Depth transducer connections


For details on connecting an iTC-5 to the SeaTalk NG backbone and connecting transducers to the iTC-5, refer to the documentation provided with the iTC-5:

iTC-5 documentation link

www.bit.ly/itc-5-docs

12.5 Transducer pod connections

Analog transducer data can be transmitted to the display using legacy transducer pods.



- Analog transducer (e.g.: speed and temperature transducer)
- Transducer pod (e.g.: Speed pod)
- SeaTalk NG T-Piece connector (A06028)


Connect the transducer to the pod, the pod terminals are color-coded, ensure that each wire is connected to the corresponding terminal.

Connect the pod to the SeaTalk NG backbone using a SeaTalk NG to bare wire spur cable (e.g.: A06043) and a T-piece connector. Pods must be located no farther than 400 mm (15.75 in.) from the connection point on the backbone.


Connecting legacy transducer pods to SeaTalk NG

Legacy transducer pods use color coded, spring retention connectors for the SeaTalk NG connection. A bare ended SeaTalk NG spur cable (e.g.: A06043) is required.

1. Prepare the bare ended wires of the SeaTalk NG spur cable as shown below:




2. Fit each wire into the corresponding color coded connector. To fit the wires use a flat blade screw driver to push in the spring retention clip and hold it in the open position, then slide the wire fully into the connector and release the spring retention clip.



Fitting spade connectors to transducer wires

Legacy transducer pods use color coded male spade connectors for the transducer connection. 1/8th size female spade connectors are required to be fitted to the transducer wires.

If spade terminals need to be fitted follow the steps below:




1. Prepare the cable as shown in 1 above.
2. Fold back the wire strands and insert into the spade connector as shown in 2 above.
3. Ensure the wire strands do not extend beyond the rear of the spade connector insulation.
4. Crimp the connector to the wire.

Connecting transducers to legacy transducer pods

Follow the steps below to connect the transducer wires to the transducer pod.

Example — Wind pod connection



1. Fit each transducer wire to the relevant color coded connector on the transducer pod.

2. Ensure each spade terminal is pushed fully on to the pod connector.

CHAPTER 13: OPERATION

CHAPTER CONTENTS

- [13.1 Operation instructions — page 49](#)

13.1 Operation instructions

For operation instructions, please refer to the i70 / i70s Operation Instructions (81401).

Document	Number	Link
i70 / i70s <i>Operation Instructions</i>	81401	www.bit.ly/i70-docs

CHAPTER 14: MAINTENANCE

CHAPTER CONTENTS

- 14.1 Service and maintenance — page 51
- 14.2 Routine equipment checks — page 51
- 14.3 Cleaning the display case — page 51
- 14.4 Cleaning the display screen — page 51
- 14.5 Cleaning the sun cover — page 51

14.1 Service and maintenance

This product contains no user serviceable components. Please refer all maintenance and repair to authorized Raymarine dealers. Unauthorized repair may affect your warranty.

14.2 Routine equipment checks

It is recommended that you perform the following routine checks, on a regular basis, to ensure the correct and reliable operation of your equipment:

- Examine all cables for signs of damage or wear and tear.
- Check that all cables are securely connected.

Caution: Product cleaning

When cleaning products:

- Switch off power supply.
- Use a clean damp cloth to wipe clean.
- Do NOT use: abrasive, acidic, ammonia, solvent or other chemical-based cleaning products.
- Do NOT use a jet wash.

14.3 Cleaning the display case

The display is a sealed unit and does not require regular cleaning. If it is necessary to clean the display, follow this basic procedure:

1. Switch off the power to the display.
2. Wipe the case with a clean, lint-free cloth.
3. If necessary, use a mild detergent to remove grease marks.

14.4 Cleaning the display screen

A coating is applied to the display screen. This makes it water repellent, and prevents glare. To avoid damaging this coating, follow this procedure:

1. Switch off the power to the display.
2. Rinse the screen with fresh water to remove all dirt particles and salt deposits.

3. Allow the screen to dry naturally.
4. If any smears remain, very gently wipe the screen with a clean microfibre cleaning cloth.

Transducer cleaning

You must clean your transducer regularly to remove organic growth. Organic growth can build up quickly on the bottom face of your transducer; this can impact transducer performance in a matter of weeks.

Important:

- When cleaning growth from an anti-fouled transducer, take care not to let paint dust and other debris enter the water, as this can have an impact on aquatic life.
- Take care not to scratch the surface of the transducer as this can impact transducer performance.
- Do NOT use harsh cleaning solvents such as acetone as this will damage the transducer.

Follow the guidance below to clean growth from your transducer:

- Use a soft cloth and a mild household cleaning detergent to clean mild growth build up.
- Use a scouring pad, such as a green Scotch Brite™ pad and a mild household cleaning detergent to clean moderate growth build up.
- You may need to use a fine grade wet and dry paper and a mild household cleaning detergent to clean severe build up.

14.5 Cleaning the sun cover

The supplied sun cover features an adhesive surface. In certain conditions unwanted contaminants may stick to this surface. To avoid damaging the monitor display, clean the sun cover regularly following this procedure:

1. Carefully remove the sun cover from the display.
2. Rinse the sun cover with fresh water to remove all dirt particles and salt deposits.
3. Allow the sun cover to dry naturally.

CHAPTER 15: TROUBLESHOOTING

CHAPTER CONTENTS

- [15.1 Troubleshooting — page 53](#)
- [15.2 Power up troubleshooting — page 53](#)
- [15.3 System data troubleshooting — page 54](#)
- [15.4 Miscellaneous troubleshooting — page 55](#)
- [15.5 Performing a Factory Reset — page 55](#)

15.1 Troubleshooting

The troubleshooting section provides possible causes and the corrective action required for common problems that are associated with the installation and operation of your product.

Before packing and shipping, all products are subjected to comprehensive testing and quality assurance programs. If you do experience problems with your product, this section will help you to diagnose and correct problems to restore normal operation.

If after referring to this section you are still having problems with your product, please refer to the *Technical support and servicing* section of this manual for useful links and contact details.

15.2 Power up troubleshooting

Product does not turn on or keeps turning off

Possible causes	Possible solutions
Blown fuse / tripped breaker	<ol style="list-style-type: none">1. Check condition of the SeaTalk NG backbone power connection 5 A fuse and if applicable distribution panel breaker, replace if necessary.2. If the fuse keeps blowing check for cable damage, broken connector pins or incorrect wiring.
Poor / damaged / insecure cables and connections	<ol style="list-style-type: none">1. Check the vessel's battery voltage and the condition of the battery terminals and power supply cables, ensuring connections are secure, clean and free from corrosion. Replace if necessary.2. Check all SeaTalk NG cabling and connections for signs of damage or corrosion. Replace if necessary.3. Check all SeaTalk NG connectors are correctly orientated, fully inserted and in the locked position.4. With the display turned on, try flexing the display's spur cable near to the display's connector to see if this causes the display to restart or lose power. Replace if necessary.5. With the product under load, using a multi-meter, check for high voltage drop across all connectors / fuses etc, and replace if necessary.
Incorrect power connection	<ol style="list-style-type: none">1. The power supply may be wired incorrectly, ensure the SeaTalk NG power connection instructions have been followed and that the backbone has one single source of 12 V dc power.

Product will not start up (restart loop)

Product causes	Possible solutions
Power supply and connection	1. Refer to 'Product does not turn on or keeps turning off' information above.
Software corruption	<div>1. In the unlikely event that the product's software has become corrupted, try downloading and installing the latest software from the Raymarine website. refer to your Multifunction Display's operation instructions for details on updating software for SeaTalk NG devices.</div> <div>2. In the case of a restart loop attempt a factory reset using the following instructions: p.55 — Performing a Factory Reset</div>

15.3 System data troubleshooting

Aspects of the installation can cause problems with the data shared between connected equipment. Such problems, their possible causes and solutions are described here.

Expected data is unavailable at all displays

Possible causes	Possible solutions
Data is not being received at the display.	1. Check the relevant product and or network cabling and connections (e.g. SeaTalk NG backbone) for signs of damage or corrosion, and replace if necessary.
Data source (e.g. instrument display or engine interface) is not operating.	<div>1. Check the source of the missing data (e.g. transducer or engine interface) for signs of damage or corrosion, and replace if necessary.</div> <div>2. If possible, check that the data source is correctly powered and operational.</div> <div>3. Refer to the instructions provided with the equipment to ensure it has been correctly installed.</div>
Software mismatch between equipment may prevent communication.	1. Ensure all products have the latest software installed.

Expected data is missing from some but not all displays

Possible causes	Possible solutions
Connection problem.	1. Check the product's SeaTalk NG spur cable and connections for signs of damage or corrosion, and replace if necessary.
Software corruption.	1. In the unlikely event that the product's software has become corrupted, try downloading and installing the latest software from the Raymarine website. refer to your Multifunction Display's operation instructions for details on updating software for SeaTalk NG devices. 2. In the case of a restart loop attempt a factory reset using the following instructions: p.55 — Performing a Factory Reset
Software mismatch between equipment may prevent communication.	1. Ensure all products have the latest software installed.

Incorrect data reported

Possible causes	Possible solutions
Transducer calibration error.	1. Switch off power supply to system and switch back on again. 2. Re-calibrate or re-configure data source following instructions provided with the relevant devices.

15.4 Miscellaneous troubleshooting

Miscellaneous problems and their possible causes and solutions are described here.

Display behaves erratically

Frequent unexpected resets, system crashes and other erratic behavior

Possible causes	Possible solutions
Intermittent problem with power to the display.	1. Check relevant fuses and breakers. 2. Check that the power supply cable is sound and that all connections are tight and free from corrosion. 3. Check that the power source is of the correct voltage and sufficient current.
Software mismatch between equipment may prevent communication.	1. Ensure all products have the latest software installed.
Corrupt data / other unknown issue.	1. In the unlikely event that the product's software has become corrupted, try downloading and installing the latest software from the Raymarine® website. Refer to your multifunction display's operation instructions for details on updating software for SeaTalk NG devices. 2. Check the data source for correct operation.

15.5 Performing a Factory Reset

To reset your unit to factory default settings follow the steps below.

Note:

Performing a factory reset will erase all saved data and customized settings.

1. Press the *[Menu]* button.
2. Select *[Set Up]*.
3. Select *[Factory Reset]*.
4. Select *[Yes]*.

Your unit will now reset itself to factory default settings.

CHAPTER 16: TECHNICAL SUPPORT

CHAPTER CONTENTS

- 16.1 Raymarine technical support and servicing — page 58
- 16.2 Checking hardware and software information — page 59

16.1 Raymarine technical support and servicing

Raymarine provides a comprehensive product support service, as well as warranty, service, and repairs. You can access these services through the Raymarine website, telephone, and e-mail.

Product information

If you need to request service or support, please have the following information to hand:

- Product name.
- Product identity.
- Serial number.
- Software application version.
- System diagrams.

Servicing and warranty

Raymarine offers dedicated service departments for warranty, service, and repairs.

Visit the Raymarine website to **read the latest warranty policy**, and **register** your product's warranty online:

- www.bit.ly/rym-warranty

United Kingdom (UK), EMEA, and Asia Pacific:

- Web: www.bit.ly/rym-service
- Tel: +44 (0)1329 246 932

United States (US):

- Web: www.bit.ly/rym-service
- Tel: +1 (603) 324 7900

Web support

Please visit the “Support” area of the Raymarine website for:

- **Manuals and Documents** — www.bit.ly/rym-docs
- **Technical support forum** — www.bit.ly/rym-support
- **Software updates** — www.bit.ly/rym-software

Telephone and online support

Region	Contact details
All regions	Online support: www.bit.ly/rym-support
United Kingdom (UK) and EMEA	Telephone: +44 (0)1329 246 777 Address: Marine House, Cartwright Drive, Fareham, PO15 5RJ, UK.
United States (US)	Telephone: Tel: +1 (603) 324 7900 (Toll-free: +800 539 5539) Address: 110 Lowell Road, Hudson, NH 03051, USA.
Australia and New Zealand (Raymarine subsidiary)	Telephone: +61 2 8977 0300 Address: Suite 1.01, 26 Rodborough Road, Frenchs Forest, NSW, 2086, Australia.
France (Raymarine subsidiary)	Telephone: +33 (0)1 46 49 72 30 Address: 35 avenue Michel Crépeau, 17000 La Rochelle - France.
Germany (Raymarine subsidiary)	Telephone: +49 40 237 808 0 Address: Atlantic-Haus, Zirkusweg 1, 20359 Hamburg.
Italy (Raymarine subsidiary)	Telephone: +39 02 9945 1001 Address: Via L. Manara 2, 20812 Limbiate (MB), Italy.
Spain (Authorized Raymarine distributor)	Telephone: +34 96 2965 102 Email: sat@azimut.es
Netherlands / Benelux (Authorized Raymarine distributor)	Telephone: +31 (0)26 3614 905 Address: Florijnweg 21G, 6883 JN VELP, Nederland.

Region	Contact details
Sweden (Raymarine subsidiary)	Telephone: +46 (0)317 633 670 Address: Bolshedens Industriväg 18, 427 50 Billdal, Sweden.
Finland (Raymarine subsidiary)	Telephone: +358 (0)207 619 937 Address: Suomalaistentie 1-3, 02270 Espoo, Finland.
Norway (Raymarine subsidiary)	Telephone: +47 692 64 600 Address: Årvollskogen 30, 1529 Moss, Norway.
Denmark (Raymarine subsidiary)	Telephone: +45 437 164 64 Address: Centervej 7, 4600 Køge, Denmark.
Russia (Distributor)	Telephone: Tel: +7 495 788 0508 Email: info@mikstmarine.ru

16.2 Checking hardware and software information

You can check current hardware details and software version from the *[About display]* menu.

1. Press the *[Menu]* button.
2. Select *[Set-up]*.
3. Select *[Diagnostics]*.
4. Select *[About Display]*.

A range of information is displayed, including the *software version* and *Serial number*.

5. Use the *[Up]* and *[Down]* buttons to cycle through the information.

CHAPTER 17: TECHNICAL SPECIFICATION

CHAPTER CONTENTS

- 17.1 Power specification — page 61
- 17.2 Network specification — page 61
- 17.3 Environmental specification — page 61
- 17.4 Display specification — page 61
- 17.5 Conformance specification — page 61

17.1 Power specification

Specification	
Nominal supply voltage:	12 V dc
Operating voltage range:	9 V dc to 16 V dc (protected up to 32 V dc)
Current:	132 mA
Power consumption:	1.6 W
LEN (Refer to the SeaTalk NG reference manual for further information.):	3

17.2 Network specification

Specification	
Data connections:	2 x SeaTalk NG connector

17.3 Environmental specification

Specification	
Operating Temperature Range:	-25°C to 55°C (-13°F to 131°F)
Storage Temperature Range:	-30°C to 70°C (-22°F to 158°F)
Relative Humidity:	93% Max.
Waterproof rating:	IPx6

17.4 Display specification

Specification	
Display screen:	4.1" TFT LCD display
Color:	16 bit color (64k colors)
Resolution:	320(H) x 240(V)
Brightness:	700 cd/m2

17.5 Conformance specification


Specification	
Conformance:	<ul style="list-style-type: none">• Europe 2004/108/EC• Australia and New Zealand C-Tick, compliance level 2

CHAPTER 18: SPARES AND ACCESSORIES

CHAPTER CONTENTS

- 18.1 Spares and accessories — page 63
- 18.2 Smart transducers — page 63
- 18.3 Instrument Depth, Speed and Temperature (DST) transducers — page 63
- 18.4 Instrument Depth transducers — page 64
- 18.5 Instrument Speed and Temperature transducers — page 65
- 18.6 RSW-Series transducers — page 65
- 18.7 Instrument Wind Vane transducer — page 65
- 18.8 Instrument Rotavecta transducer — page 66
- 18.9 Other transducers — page 66
- 18.10 SeaTalk NG cables and accessories — page 67

18.1 Spares and accessories




Part number	Description
R22168	Spare bezel
R22169	Sun cover

18.2 Smart transducers

Smart transducers can be connected directly to the SeaTalk NG backbone without the need for an iTC-5 or transducer pod. The smart transducers listed below are compatible with the following displays:

- i70s / i70.
- Multifunction displays.




Part number	Transducer description
E70617 / E70667	DST810 –0° Thru-Hull
E70618	DT810 –0° Thru-Hull

Part number	Transducer description
E70619	DT810 –12° Thru-Hull
A22146	DST800 Bronze Thru-Hull
A80375	DST800 Plastic Thru-Hull (replaces A22111)
A22147	DT800 –12° Bronze Thru-Hull
A80374	DT800 –12° Plastic Thru-Hull (replaces A22112)

18.3 Instrument Depth, Speed and Temperature (DST) transducers

The DST transducers listed below are compatible with the following instrument displays:

- i40 Depth / i40 Speed / i40 Bidata.
- i50 Depth / i50 Speed / i50 Tridata.
- i70s / i70 via iTC-5 converter.




Part number	Transducer description
A22154	DST-800 Thru-hull
E26028–PZ	P66 Transom mount
E26006–PZ	P65 / ST40 Transom mount

Part number	Transducer description
A26043	B744V (including fairing block) Thru-hull
A26044	B744VL (including fairing block) Thru-hull

18.4 Instrument Depth transducers

The depth transducers listed below are compatible with the following instrument displays:

- i50 Depth / i50 Tridata.
- i70s / i70 via iTC-5 converter.




Part number	Transducer description
E26009	P7 Thru-hull
E26019-PZ	B45 (including fairing block) Thru-hull
M78717	B17 Thru-hull
M78713-PZ	P319 Thru-hull
E26030	P17 Thru-hull
E26001-PZ	P79 In-hull
A80373 — T70278	P79S In-hull — (includes SeaTalk NG adaptor)
E26027-PZ	P66 Transom mount

18.5 Instrument Speed and Temperature transducers

The speed and temperature transducers listed below are compatible with the following instrument displays:

- i40 Speed / i40 Bidata.
- i50 Speed / i50 Tridata.
- i70s / i70 via iTC-5 converter.




Part number	Description
E25025	P17 Thru-hull
E26031	ST800 -P120 Thru-hull.
E70673	ST900 -P120 Thru-hull, with 13.7 m (44.95 ft) fitted cable.
E70674	ST900 -P120 Thru-hull, with 20 m (65.62 ft) fitted cable.
E66072	ST800 -B120 Thru-hull.
E70686	ST900 -B120 Thru-hull, with 13.7 m (44.95 ft) fitted cable.
E70687	ST950 -P17 Thru-hull with 6 m (19.69 ft) fitted cable.

Part number	Description
E26008	P371 Thru-hull.
E26005	ST69 Transom mount.

18.6 RSW-Series transducers

RSW (Raymarine Smart Wind) transducers can be connected directly to the SeaTalk NG backbone using the wired gateway.




Part number	Description
E70670	RSW-Wired Performance transducer and NMEA 2000 wired gateway.

18.7 Instrument Wind Vane transducer

The wind vane transducers listed below are compatible with the following instrument displays:

- i60 Wind
- i70s / i70 via the iTC-5 converter.




Part number	Transducer description
E22078	Short-Arm Masthead Wind vane transducer
E22079	Long-Arm Masthead Wind vane transducer

18.8 Instrument Rotavecta transducer

The wind transducers listed below are compatible with the following instrument displays:


- i40 Wind.
- i60 Wind.
- i70s / i70 via the iTC-5 converter.



Part number	Transducer description
Z195	Rotavecta transducer

18.9 Other transducers

When connected using an iTC-5 , the transducers listed below are compatible with the your i70s / i70 display:




Part number	Transducer description
M81190	Fluxgate compass
M81105	Rudder Reference

18.10 SeaTalk NG cables and accessories

SeaTalk NG cables and accessories for use with compatible products.


SeaTalk NG kits

SeaTalk NG kits enable you to create a simple SeaTalk NG backbone.
Starter kit (part number: T70134) consists of:




- 1 x Spur cable 3 m (9.8 ft) (part number: **A06040**). Used to connect device to the SeaTalk NG backbone.
- 1 x Power cable 2 m (6.6 ft) (part number: **A06049**). Used to provide 12 V dc power to the SeaTalk NG backbone.
- 2 x Backbone terminators (part number: **A06031**). Terminators must be fitted to both ends of the SeaTalk NG backbone.
- 1 x 5-Way connector (part number: **A06064**). Each connector block allows connection of up to 3 SeaTalk NG devices. Multiple connector blocks can be 'daisy chained' together.

Backbone kit (part number: A25062) consists of:



- 2 x Backbone cables 5 m (16.4 ft) (part number: **A06036**). Used to create and extend the SeaTalk NG backbone.
- 1 x Backbone cable 20 m (65.6 ft) (part number: **A06037**). Used to create and extend the SeaTalk NG backbone.
- 4 x T-piece (part number: **A06028**). Each T-piece allows connection of one SeaTalk NG device. Multiple T-pieces can be 'daisy chained' together.
- 2 x Backbone terminators (part number: **A06031**). Terminators must be fitted to both ends of the SeaTalk NG backbone.
- 1 x Power cable 2 m (6.6 ft) (part number: **A06049**). Used to provide 12 V dc power to the SeaTalk NG backbone.


Evolution-Series autopilot cable kit (part number: R70160) consists of:



- 1 x Backbone cable 5 m (16.4 ft) (part number: **A06036**). Used to create and extend the SeaTalk NG backbone.
- 1 x Spur cable 1 m (3.3 ft) (part number: **A06040**). Used to connect device to the SeaTalk NG backbone.
- 1 x Power cable 2 m (6.6 ft) (part number: **A06049**). Used to provide 12 V dc power to the SeaTalk NG backbone.


4. 1 x 5-Way connector (part number: **A06064**). Each connector block allows connection of up to 3 SeaTalk NG devices. Multiple connector blocks can be 'daisy chained' together.
5. 2 x T-pieces (part number: **A06028**). Each T-piece allows connection of one SeaTalk NG device. Multiple T-pieces can be 'daisy chained' together.
6. 2 x Backbone terminators (part number: **A06031**). Terminators must be fitted to both ends of the SeaTalk NG backbone.

SeaTalk 1 to SeaTalk NG converter kit (part number: E22158) consists of:



1. 1 x Power cable 2 m (6.6 ft) (part number: **A06049**). Used to provide 12 V dc power to the SeaTalk NG backbone.
2. 1 x Spur cable 1 m (3.3 ft) (part number: **A06039**). Used to connect a device to the SeaTalk NG backbone.
3. 1 x SeaTalk 1 (3 pin) to SeaTalk NG adapter cable 0.4 m (1.3 ft) (part number: **A22164**). Used to connect SeaTalk 1 devices to the SeaTalk NG backbone via the SeaTalk 1 to SeaTalk NG converter.
4. 1 x SeaTalk 1 to SeaTalk NG converter (part number: **E22158**). Each converter allows connection of one SeaTalk 1 device and up to 2 SeaTalk NG devices.
5. 2 x Spur blanking plugs (part number: **A06032**). Used to cover unused spur connections in 5-way blocks, T-piece connectors and SeaTalk 1 to SeaTalk NG converter.
6. 2 x Backbone terminators (part number: **A06031**). Terminators must be fitted to both ends of the SeaTalk NG backbone.


NMEA 0183 VHF 2-wire to SeaTalk NG converter kit (part number: E70196) consists of:



1. 1 x Power cable 2 m (6.6 ft) (part number: **A06049**). Used to provide 12 V dc power to the SeaTalk NG backbone.
2. 1 x Spur cable 1 m (3.3 ft) (part number: **A06039**). Used to connect a device to the SeaTalk NG backbone.
3. 1 x NMEA 0183 VHF stripped-end (2-wire) to SeaTalk NG adapter cable 1 m (3.3 ft) (part number: **A06071**). Used to connect an NMEA 0183 VHF radio to the SeaTalk NG backbone via the NMEA 0183 to SeaTalk NG converter.
4. 1 x SeaTalk 1 to SeaTalk NG converter (part number: **E22158**). Each converter allows connection of one SeaTalk 1 device and up to 2 SeaTalk NG devices.
5. 2 x Spur blanking plugs (part number: **A06032**). Used to cover unused spur connections in 5-way blocks, T-piece connectors, and the SeaTalk 1 to SeaTalk NG converter.
6. 2 x Backbone terminators (part number: **A06031**). Terminators must be fitted to both ends of the SeaTalk NG backbone.

SeaTalk NG spur cables


SeaTalk NG spur cables are required to connect devices to the SeaTalk NG backbone.



- SeaTalk NG spur cables:
 - Spur cable 0.4 m (1.3 ft) (part number: **A06038**).
 - Spur cable 1 m (3.3 ft) (part number: **A06039**).
 - Spur cable 3 m (9.8 ft) (part number: **A06040**).
 - Spur cable 5 m (16.4 ft) (part number: **A06041**).
- Elbow (right-angled) to elbow (right-angled) spur cable 0.4 m (1.3 ft) (part number: **A06042**). Used in confined spaces where a straight spur cable will not fit.
- Elbow (right-angled) to straight spur cable 1 m (3.3 ft) (part number: **A06081**). Used in confined spaces where a straight spur cable will not fit.
- SeaTalk NG to stripped-end spur cables (connects compatible products that do not have a SeaTalk NG connector, such as transducer pods):
 - SeaTalk NG to stripped-end spur cable 1 m (3.3 ft) (part number: **A06043**)
 - SeaTalk NG to stripped-end spur cable 3 m (9.8 ft) (part number: **A06044**)
- ACU-Series / SPX-Series autopilot to SeaTalk NG spur cable 0.3 m (1.0 ft) (part number **R12112**). Connects the course computer to the SeaTalk NG backbone. This connection can also be used to provide 12 V dc power to the SeaTalk NG backbone.

SeaTalk NG backbone cables

SeaTalk NG backbone cables are used to create or extend a SeaTalk NG backbone.




- Backbone cables:
 - Backbone cable 0.4 m (1.3 ft) (part number: **A06033**).
 - Backbone cable 1 m (3.3 ft) (part number: **A06034**).
 - Backbone cable 3 m (9.8 ft) (part number: **A06035**).
 - Backbone cable 5 m (16.4 ft) (part number: **A06036**).
 - Backbone cable 9 m (29.5 ft) (part number: **A06068**).

- Backbone cable 20 m (65.6 ft) (part number: **A06037**).
- SeaTalk NG to DeviceNet (female) Backbone cable 0.4 m (1.3 ft) (part number: **A80675**)
 - SeaTalk NG to DeviceNet (male) Backbone cable 0.4 m (1.3 ft) (part number: **A80674**)

SeaTalk NG power cables


SeaTalk NG power cables are used to provide the SeaTalk NG backbone with a single 12 V dc power source. The power connection must include a 5 amp inline fuse (not supplied).



- Power cable (straight) 2 m (6.6 ft) (part number: **A06049**).
- Elbow (right-angled) power cable 2 m (6.6 ft) (part number: **A06070**).

SeaTalk NG connectors

SeaTalk NG connectors are used to connect SeaTalk NG devices to the SeaTalk NG backbone and to create and extend the backbone.




- 5-Way connector (part number: **A06064**). Each connector block allows connection of up to 3 SeaTalk NG devices. Multiple connector blocks can be 'daisy chained' together.
- T-piece (part number: **A06028**). Each T-piece allows connection of one SeaTalk NG device. Multiple T-pieces can be 'daisy chained' together.
- Backbone extender (part number: **A06030**). Used to connect 2 backbone cables together.
- Inline terminator (part number: **A80001**). Used to connect a spur cable and SeaTalk NG device at the end of a backbone instead of a backbone terminator.

5. Backbone terminator (part number: **A06031**). Terminators must be fitted to both ends of the SeaTalk NG backbone.
6. Spur blanking plug (part number: **A06032**). Used to cover unused spur connections in 5-Way blocks, T-piece connectors, or the SeaTalk 1 to SeaTalk NG converter.
7. Elbow (right-angled) spur connector (part number: **A06077**). Used in confined spaces where a straight spur cable will not fit.

SeaTalk NG adaptors and adaptor cables

SeaTalk NG adaptor cables are used to connect devices designed for different CAN Bus backbones (e.g.: SeaTalk 1 or DeviceNet) to the SeaTalk NG backbone.



1. SeaTalk 1 (3 pin) to SeaTalk NG converter cable 1 m (3.3 ft) (part number: **A22164 / A06073**). Can be used to connect a SeaTalk 1 device to a SeaTalk NG backbone via the SeaTalk 1 to SeaTalk NG converter, or to connect a SeaTalk NG product directly to a SeaTalk 1 network.
2. SeaTalk 1 (3 pin) to SeaTalk NG adaptor cable 0.4 m (1.3 ft) (part number: **A06047**). Can be used to connect a SeaTalk 1 device to a SeaTalk NG backbone via the SeaTalk 1 to SeaTalk NG converter, or to connect a SeaTalk NG product directly to a SeaTalk 1 network.
3. SeaTalk 2 (5 pin) to SeaTalk NG adaptor cable 0.4 m (1.3 ft) (part number: **A06048**). Used to connect SeaTalk 2 devices or networks to a SeaTalk NG backbone.
4. SeaTalk NG to DeviceNet (female) adaptor cables connect NMEA 2000 devices that use a DeviceNet connector to the SeaTalk NG

backbone, or connects SeaTalk NG devices to an NMEA 2000 network. The following cables are available:

- SeaTalk NG to DeviceNet (female) adaptor cable 0.4 m (1.3 ft) (part number: **A06045**).
 - SeaTalk NG to DeviceNet (female) adaptor cable 1 m (3.3 ft) (part number: **A06075**).
5. SeaTalk NG to DeviceNet (male) adaptor cables. Connect NMEA 2000 devices that use a DeviceNet connector to the SeaTalk NG backbone, or connect SeaTalk NG devices to an NMEA 2000 network. The following cables are available:
 - SeaTalk NG to DeviceNet (male) adaptor cable 0.1 m (0.33 ft) (part number: **A06078**).
 - SeaTalk NG to DeviceNet (male) adaptor cable 0.4 m (1.3 ft) (part number: **A06074**).
 - SeaTalk NG to DeviceNet (male) adaptor cable 1 m (3.3 ft) (part number: **A06076**).
 - SeaTalk NG to DeviceNet (male) adaptor cable 1.5 m (4.92 ft) (part number: **A06046**).
 6. NMEA 0183 stripped-end (2-wire) to SeaTalk NG adapter cable 1 m (3.3 ft) (part number: **A06071**). Used to connect an NMEA 0183 VHF radio to the SeaTalk NG backbone via the NMEA 0183 to SeaTalk NG converter.
 7. SeaTalk NG (male) to DeviceNet (female) adaptor (**A06082***).
 8. SeaTalk NG (female) to DeviceNet (male) adaptor (**A06083***).
 9. SeaTalk NG (male) to DeviceNet (female) elbow (right-angled) adaptor (**A06084***).
 10. DeviceNet (female) to stripped-end adaptor cable (0.4 m (1.3 ft)) (part number: **E05026**).
 11. DeviceNet (male) to stripped-end adaptor cable (0.4 m (1.3 ft)) (part number: **E05027**).

Important:

* Do NOT connect the A06082, A06083, or A06084 adaptors directly to a backbone. Only connect as part of a **spur** connection between backbone and device.

Appendix A Supported NMEA 2000 PGN list

Administration PGNs

- **59392** — ISO Acknowledge (Receive / Transmit)
- **59904** — ISO Request (Receive / Transmit)
- **60928** — ISO Address Claim (Receive / Transmit)
- **126208** — NMEA® — Request, Commanded, Acknowledged Group Function (Receive / Transmit)
- **126464** — PGN Transmit and Receive List (Receive / Transmit)
- **126996** — Product Information (Receive / Transmit)

Raymarine provides field programmability of the Device and System Instances within PGN 60928 which can be commanded via use of PGN 126208, as required by the latest NMEA 2000 standard.

Data PGNs

- **127237** — Heading/Track Control (Receive)
- **127245** — Rudder (Receive / Transmit)
- **127250** — Vessel Heading (Receive / Transmit)
- **127251** — Rate of Turn (Receive / Transmit)
- **127257** — Attitude (Receive)
- **127258** — Magnetic Variation (Receive / Transmit)
- **127488** — Engine Parameters, Rapid Update (Receive)
- **127489** — Engine Parameters, Dynamic (Receive)
- **127493** — Transmission Parameters, Dynamic (Receive)
In software version v3.20 onwards, the following warnings are supported:
 - Check Transmission
 - Over Temperature
 - Low Oil Pressure
 - Low Oil Level
 - Sail Drive
- **127496** — Trip Parameters, Vessel (Receive)
- **127497** — Trip Parameters, Engine (Receive)
- **127498** — Engine Parameters, Static (Receive)

- **127505** — Fluid Level (Receive)
- **127506** — DC detailed status (Receive)
- **127508** — Battery status (Receive)
- **128259** — Speed, (Receive / Transmit)
- **128267** — Water Depth (Receive / Transmit)
- **128275** — Distance Log (Receive / Transmit)
- **129025** — Position, Rapid Update (Receive / Transmit)
- **129026** — COG & SOG, Rapid Update (Receive / Transmit)
- **129029** — GNSS Position Data (Receive / Transmit)
- **129033** — Time & Date (Receive / Transmit)
- **129038** — AIS Class A Position Report (Receive)
- **129039** — AIS Class B Position Report (Receive)
- **129040** — AIS Class B Extended Position Report (Receive)
- **129041** — AIS Aids to Navigation (AtoN) Report (Receive)
- **129044** — Datum (Receive / Transmit)
- **129283** — Cross Track Error (Receive / Transmit)
- **129284** — Navigation Data (Receive / Transmit)
- **129291** — Set & Drift, Rapid Update (Receive)
- **129801** — AIS Addressed Safety Related Message (Receive)
- **129802** — AIS Safety Related Broadcast Message (Receive)
- **129809** — AIS Class B "CS" Static Report, Part A (Receive)
- **129810** — AIS Class B "CS" Static Report, Part B (Receive)
- **130306** — Wind Data (Receive / Transmit)
- **130310** — Environmental Parameters (Receive / Transmit)
- **130311** — Environmental Parameters (Receive / Transmit)
- **130312** — Temperature (Receive)
- **130316** — Temperature, Extended Range (Receive)
- **130576** — Small Craft Status (Receive)
- **130577** — Direction Data (Receive)

Appendix B Document change history

Documentation for current products is regularly updated to ensure accuracy and reflect changing product features and / or specifications. Changes made to this document since its last revision are listed below.

Document number:	Document name:
87425	i70 Installation Instructions

Changes:

Revision	Date
2	October 2025

- Updated SeaTalk NG power connection details to latest standards.
- Updated to include smart transducer direct connection to SeaTalk NG.
- Added RSW transducer connection example.
- Added DST810 connection details.
- Updated iTC-5 SeaTalk NG connection details.
- Updated transducer lists in spares and accessories chapter.
- Added PGN 130312 and 130316 to list of supported PGNs.

Changes:

Revision	Date
1	May 2021

- Initial release. For Operation instructions, refer to document 81401.

Index

A

Accessories	
SeaTalk NG adaptor cables.....	70
SeaTalk NG backbone cables.....	69
SeaTalk NG cables.....	67
SeaTalk NG connectors	69
SeaTalk NG kits.....	67
SeaTalk NG Power cables	69
SeaTalk NG spur cables.....	68

B

Backbone length,	
SeaTalk NG.....	36
Bezel removal.....	25

C

Cable	
Bend radius.....	29
Protection	29
Routing	29
Security.....	29
Strain relief.....	29
Cleaning.....	51
Screen	51
Cleaning the transducer.....	51
Compass safe distance	22
Connections.....	42
Battery	38
DeviceNet.....	30
Distribution panel	37
DST810	44
Overview	30
Power	34, 36, 39
Power connections	
Power distribution.....	37
SeaTalk 1.....	30
SeaTalk NG.....	30
Smart transducer	44

Transducers	44
-------------------	----

D

Declaration of Conformity.....	9
Distribution panel connection.....	37
Document history	72
Documentation	
Installation instructions.....	12
Mounting template.....	12
Operation instructions	12

E

Electromagnetic Compatibility	22
EMC, <i>See</i> Electromagnetic Compatibility	

F

Fuse requirement	34
------------------------	----

I

Inline fuse	34
Interference.....	22
<i>See also</i> Compass safe distance	
iTC-5 connection	45
iTC-5 connections.....	45

L

Load equivalency number.....	36
Location requirements	22
Viewing angle.....	22

M

Maintenance.....	51
------------------	----

Mounting	27
----------------	----

N

Network length, SeaTalk NG	36
NMEA 2000	71
LEN	30, 36
NMEA 2000 connection	42

O

Operation instructions	12, 49
------------------------------	--------

P

PGNs	71
Power	
Battery connection	38
Distribution panel	37
Fuses	34
Sharing a breaker	37
Power cable extension	35, 38
Power connection point	36
Power troubleshooting	53
Product dimensions	20
Product loading	30, 36
Product overview	14
Product recycling (WEEE)	10
Product support	58

R

Routine checks	51
RSW transducer	44

S

SeaTalk	42
SeaTalk NG	30, 37, 42

Adaptor cables	70
Backbone cables	69
Connectors	69
iTC-5 connections	45
Kits	67
Legacy transducer pod connection	46
LEN	30, 36
Load equivalency number	30, 36
Power	34, 36, 39
Power cables	35, 69
Spur cables	68
System loading	36
SeaTalk NG cables	67
Service Center	58
Servicing	51
Software updates	14
Spade terminals	46
System example	44
System examples	
Expanded system	15, 31
Typical system	15, 31

T

Technical specification	
Conformance specification	61
Display specification	61
Environmental specification	61
Network specification	61
Power specification	61
Technical support	58
Tools required	25
Transducer pod	45
Transducers	
Fluxgate compass	66
Rotavecta	66
RSW transducer	65
Rudder reference	66
Smart transducers	63
Wind Vane	65
Troubleshooting	53

U

Upgrading, software..... 14

W

Warranty..... 10, 58
WEEE Directive 10